



Attention Installer or Homeowner!

Follow these guidelines to prevent damage to your new window sash

- Store all window sash in a dry environment, before and after finishing the interior wood surfaces prior to installation.
- Extreme care is to be used during handling to prevent damage to the exterior aluminum cladding and the interior wood surfaces.
- Apply the paint primer/ or stain and then the finish top coating up to the aluminum cladded edge for full protection.

 **DO NOT** use water based paint primer or water based stain on this sash. Water based products may cause warping of the wood components and damage to the structure of the window sash... 

Using water based finish products voids the PWD Service Warranty.

- Finish the interior wood surfaces *as soon as* possible after receipt & store window sash in the delivery freight containers until this step is started.
- After finish application, lay window sash flat [cladded side down on a protected surface] or vertically on sash short side edge until paint/ stain [sealer coat] finish application has cured.
- No consideration for any warranty claims will be given if the window sash is not finished coated [paint or stain] prior to installation.
- Proper installation of the mechanical operating system is required to prevent damage to the window sash.
- Contact your sales representative at PWD Service with any questions.